



Road Vehicle In- Cabin TrainSense™ Device providing Driver audible / visual pre- alerts



GPS inside LSM TrainSense™ Device continually checks Vehicle location co- ordinates against Rail Crossing mapped coordinate data

“ACTIVE” Railway level Crossing with Flashing Lights Bell / Boom Gates activated by Existing Trackside Signal Switches

LSM TrainSense®



“PASSIVE” Railway Level Crossing with no (or) Flashing Lights Bells or only Static Warning Signs

